

# “Designed for You and Your Success

Efficient · Powerful · Flexible

Our new **SG-Economy** suction system is powerful and versatile.

## OUR PROVEN FORMULA FOR SUCCESS:

We combine technology, experience, expertise, and team spirit.



## Always available for you

Do you want to request a quote, order products, or have questions about your order, delivery, or warranty?

We look forward to your call and are happy to assist you.



[www.wassermann.hamburg](http://www.wassermann.hamburg)



[fb.com/WassermannDentalmaschinen](https://fb.com/WassermannDentalmaschinen)

## Suction Unit SG-Economy



## Info-Hotline

+49 (0)40 730 926-0



SCAN ME

# Suction Unit SG-ECONOMY



## Our new SG-Economy suction system ...

combines outstanding suction and filtration performance with maximum efficiency at minimal operating costs.

It is designed for extracting dental dust at the workstation and for removing polishing dust from devices such as sandblasters, micromotors, or polishing units.



## Key Features at a Glance:

- Suction system with a highly efficient motor and convenient auto start function (auto/manual mode selectable)
- Clearly structured user interface for quick and easy operation
- Includes filter status warning and automatic main filter shaking function
- Adjustable suction power in stages (25-50-75-100%)
- Expandable to two stations (adapter available as accessory)
- Virtually silent operation, suitable for continuous use
- High safety standard: Features practical auto start and integrated after-run automation
- High health protection: 3-stage filtration system including main filter/cartridge filter class M according to EN 60335-2-69 (washable), filter bag box, and HEPA fine dust outlet filter

**SG-Economy**  
Item No. 140970

## Technical Specifications

Motor Power: 900 W  
Depression: 1900 mm / H<sub>2</sub>O

Dimension unit max. W x H x D: 24 x 48 x 37 cm  
Dimension package W x H x D: 35 x 54 x 40 cm

Weight: 13 kg net weight, 16 kg gross weight  
Sound level: ≤ 59 dB (A)

## Info & Consultation:

Wassermann Dental-Maschinen GmbH  
Rudorffweg 15 - 17  
21031 Hamburg, Germany

Tel: +49 (0)40 730 926-0  
[www.wassermann-dental.com](http://www.wassermann-dental.com)  
[sales@wassermann-dental.com](mailto:sales@wassermann-dental.com)