

“developed  
for more  
flexibility

- **efficient & powerful**

Our new **Steam Box** is a compact work cabin for cleaning workpieces by means of steam.

**OUR PROVEN RECIPE FOR SUCCESS:**

We combine technology, experience, competence and team spirit.



**Always available for you**

Would you like to request a quote or place an order? Or do you have questions about your order, delivery or warranty?

We look forward to your call and will be happy to help you.

# Steam-Box

Steam cabine with  
integrated suction system



[www.wassermann.hamburg](http://www.wassermann.hamburg)



[fb.com/WassermannDentalmaschinen](https://fb.com/WassermannDentalmaschinen)

**Service Hotline**

+49 (0)40 730 926-0



SCAN ME



## Steam-Box

Steam cabine with  
integrated suction system

**NEW** Now with more  
control functions

**QUALITY MADE IN GERMANY SINCE 1927**

**New now!** Steam cabin with suction system and integrated foot pedal and hand sensor control. Perfect protection for first-class results: Our new steam box combines maximum safety with maximum comfort.



### The most functions and features at a glance:

- Constructed for long life
- With integrated dust particle filter
- Foot pedal and hand sensor control
- Low-maintenance and easy to clean
- Compact work cabin for cleaning workpieces by means of steam
- Large working area (W= 285 mm, H= 235 mm)
- Fast steam extraction by powerful fan with overrun control
- Automatic fan operation selectable via foot pedal or hand sensor control
- Collecting tray can be emptied by means of side ball valve
- With practical handles:  
The work cabin can be quickly dismantled for cleaning the collection tray
- LED Lights for a comfortable and safe light environment

**Steam-Box**  
Art.-Nr. 174970

#### Technical Data:

Output:	140 W	W x H x D (max.):	421 x 476 x 549 mm
Power consumption:	0,8 A	W x H x D (housing):	393 x 476 x 515 mm

Weight:	26,5 kg
Protection class:	IP 44

#### Support Service:

Wassermann Dental-Maschinen GmbH  
Rudorffweg 15 - 17  
21031 Hamburg

Tel: +49 (0)40 730 926-0  
www.wassermann-dental.com  
sales@wassermann-dental.com